

Operating Instructions for Variable Frequency Controller

Temperature controller operating instructions

1. Temperature controller function

The temperature controller can remotely monitor and change some settings of the variable frequency controller, and can remotely control the operation of the variable frequency controller through 485 communications; The temperature controller is equipped with temperature and defrosting (evaporator) sensor probes, which can view real-time cabinet temperature and frequency; The temperature controller is equipped with fault display and buzzer alarm functions;

2. Operating conditions of temperature controller

Working voltage: 220VAC $\pm$ 10%, 50HZ

Working condition: -5°C~60°C,

Working relative humidity: 10%~90% (No condensation allowed); Storage temperature: -25°C~75°C;

3. Specifications and Dimensions

Dimensions: 85 * 35 * 63.8(mm), Installation Dimensions: 71 * 29,

The sensor length: 2 (m)

Sensor length of 5m optional

4. Technical Parameter

Temperature control range: -40°C~85°C;

Measuring range: -40°C~99°C

Sensor type: NTC (10KQ /25C, B 3435K)

5. Operation and display panel



The display board can display three numbers

Two status indicators (key lock, Fan),

Four parameter description words (ON temperature, OFF temperature, Def cycle, Def time).

5.1. Key Description

There are six buttons on the Temperature controller:

unlock/ok; Forced defrosting key; ON Temp; OFF Temp; up key; down key.

5.2. Work instructions

code	status	Description(EN)
	light	lock
	Extinguish	unlock
ON	Extinguish	Compressor shutdown
	flicker	Delayed startup
	flight	Compressor startup
Def	flicker (slow)	Drip water
	Extinguish	Fan stop
	flicker	Fan delay
	light	Fan run

5.3. Temperature controller unlocking, locking, user menu settings

- 1) The Temperature controller will automatically lock the buttons after 30 seconds without any button action to prevent accidental touch; When the Temperature controller is in a locked state, press and hold the "unlock button/OK" for 1 second to unlock the locked Temperature controller;

- 2) Temperature Quick Settings:

In normal operation, press the "ON Temp" key (or "OFF Temp" key), the corresponding parameter description word will light up, and the display window will display the "ON Temp" (or "OFF Temp") value, indicating that the "Start Temperature" (or "OFF Temperature") menu has been entered. You can use the "T" or "I" keys to adjust parameters, and hold down the "T" or "I" keys to quickly adjust parameters. In the setting state, exit the setting state and save the parameters by pressing and releasing the "unlock key/OK" or no button action within 30 seconds

5.4. Quick Actions

The temperature controller defaults to displaying the current library temperature.

When the temperature controller is not locked:

Click on the "unlock button/OK" to turn on or off the light; (The lamp needs to be connected to the temperature controller relay)

Press and hold "T" to view the current operating frequency.

Press and hold "I" to view the temperature of the defrosting probe.

5.5. System settings

When the temperature controller is in a non-locked state, press and hold the "unlock button/OK" for more than 5 seconds until "F1" appears to enter the temperature controller parameter setting interface


Press the "↑" or "↓" keys to convert parameter code items; Press the "Unlock key/OK" to display the corresponding parameter values, press the "↑" or "↓" keys to adjust the parameters, and hold down the button to quickly adjust the parameters; Press the 'unlock key/OK' to temporarily store the modified parameter values and return to the displayed parameter code.

In the system menu setting state, if there is no button action within 3 seconds or 30 seconds of holding down the "Unlock Key/OK" button, the modified parameter values will be saved and the system menu setting state will be exited.

Parameters	Default Value	Numeric Range	Meaning	Description
F1	10	-40~85C	ON Temp	
F2	-10	-40~85C	OFF Temp	
F3	30	0~120min	Defrosting time	Defrosting Duration
F4	6	0~120h	Defrosting cycle	
F5	3	0~120min	Defrosting and dripping time	
F6	10	-40~50C	Defrosting stop Temp	The defrost will automatically stop
F7	2	0~24h	STARTUP OVER-TEMPERATURE ALARM DELAY	No over-temperature
No over temperature alarm when the startup time is less than F7				
F8	5	0~50C	Overtemperature alarm value	Start-up temperature
F9	10	0~120min	Overtemperature alarm delay	+ F8, over-
Startup temperature+F8, over temperature alarm after lasting for more than F9 time				
F10	0	-10~10C	Cabinet temperature sensor calibration	
F11	0	-10~10C	Evaporator sensor calibration	
F12	0	0/1/2	Defrost display mode	0/1/2
0:Cabinet Temp; 1 : Display DEF ; 2: cabinet Temp at the beginning of defrosting				
F13	0	0/1/2	Fan working mode	0/1/2
0: Continuous operation; 1: Follow the compressor; 2: Stop during defrosting				
F14	0	0/1/2	Defrosting mode	0/1/2
0: Electrochemical frost; 1: Thermal fluorination cream; 2: Wind defrosting				
①F13 fan setting is only valid for the built-in fan of the temperature controller				

6. Temperature controller connection

The temperature controller can be connected to the evaporation fan and lighting. When the evaporation fan is connected to the temperature controller, the logic of the controller to the evaporation fan will become invalid, and the evaporation fan will be controlled according to the F13 setting of the temperature controller. It is usually recommended to connect the evaporation fan to the control panel, and the control mode of the evaporation fan can be automatically adjusted according to the defrosting mode; If it is necessary to connect to the temperature controller and manually control the evaporation fan, it must be confirmed that there is no conflict between the current defrosting mode and the working mode of the fan; Refer to **5.6** Temperature Controller Parameter Table for details.




Wiring diagram of temperature controller

7. Temperature controller malfunction alarm reference

When certain faults occur in the unit, the temperature controller will prompt corresponding codes and sound an alarm. The code table can be used as a reference for troubleshooting

Code	Description	Reason/Solution
E01	Ambient temperature sensor fault	Check if the corresponding sensor on the main control board has poor contact or is damaged
E02	Condensate temperature sensor fault	
E03	Discharge temperature sensor short circuit fault	
E11	Overtemperature alarm	The temperature of the cold storage cannot reach the target temperature for a long time, please check whether the system cooling is normal or whether the relevant parameters F7/8/9 are set reasonably
EC	Communication failure	Check the connection between the Thermostat and the motherboard
Er1	storage temperature sensor fault	Check if the corresponding sensor has poor contact or damage
Er2	Evaporator temperature sensor fault	

Main control board Function Description Schematic Diagram of the functional connection of the main control board



- 1) The unit can use a passive start signal to control the start and stop of the entire machine. If ON/OFF is short circuited, it will start and operate normally, and if disconnected, it will be in overall standby mode; Short circuit this port by default at the factory.
- 2) When connecting the defrosting equipment to the main control board, a relay relay should be used, and high-power equipment should not be directly connected to avoid damage to the main control board. The evaporation fan is allowed to directly connect to small power loads, and the port load of the evaporation fan shall not exceed 1.3A; The overall load of the main control board shall not exceed 3.5A

1. On/Off Control

Temperature controller switch temperature control:

The temperature controller detects the temperature inside the cabinet, and when there is no abnormal alarm from the controller, it starts and stops the control according to the set start/stop temperature;

Startup: cabinet temperature > startup temperature

Shutdown: cabinet temperature < shutdown temperature - shutdown temperature difference

The controller adjusts the compressor operating frequency based on the current cabinet temperature and the set shutdown temperature, with a default compressor startup delay of 180 seconds;

2. Fan control

2.1. Condenser Fan

After the compressor is started, the condensing fan controls the working mode of the condensing fan based on the outdoor ambient temperature and outdoor coil temperature: AC/DC fans can be selected according to demand; The AC fan is controlled on/off, while the DC fan has a speed regulation function;

AC Fan

- 1) When the ambient temperature probe detects a high temperature, the condensing fan is forced to open;
- 2) Determine the condensation temperature. When the condensation temperature is > 35°C, the condensation fan starts. When the outdoor coil is below 30°C, the fan stops (can be set)

DC Fan

After the DC fan is set, the wind speed can be automatically adjusted based on the current condensation temperature; When using DC fans, the number of fans must match the current setting. By dialing the code to select whether to enable or not to enable the DC fan (Factory preset), the starting temperature of the fan can be set;

2.2. Evaporation Fan

There are two wiring options for the evaporation fan:

- 1) Connect to the Main control board: The evaporation fan will be controlled according to the defrosting settings of (the fan working mode will be automatically adjusted according to the defrosting type);

- 2) Connect to the temperature controller: The evaporation fan will be independently controlled according to the parameters set by the temperature controller F13 (manual confirmation of the fan operating mode is required to avoid conflicts with the defrosting mode);

Evaporation Fan default working mode

- 1) The evaporation fan automatically starts after the temperature controller and variable frequency controller are powered on.
- 2) The evaporation fan does not operate in the defrosting and defrosting drip state. After the defrosting drip time is over, the evaporation fan starts (depending on the current defrosting mode operation mode)

3. Defrosting control

3.1. Defrosting type

- 1) The defrosting type can be changed by modifying the F14 parameters of the temperature controller. The operation mode of evaporation fans and defrosting relays varies for different defrosting types
- 2) Electric defrosting: The compressor stops, the evaporation fan stops running, the electric heating (connected to the relay on the variable frequency control board) starts running, and the condensing fan (connected to the relay on the variable frequency control board) stops running. (Default Mode)
- 3) Hot fluorination frost: Before using hot gas defrosting, the compressor should be stopped first, and then the defrosting relay should be turned on to start and run the compressor for defrosting. To ensure the stability of the system, the compressor should run for no less than 2 minutes. After defrosting with hot air, the compressor can only be started after a delay of 2 minutes when the conditions are met; During defrosting, the main refrigeration solenoid valve is activated, the evaporation fan is stopped, the electric heating relay is activated, and the condensation fan is activated
- 4) Wind defrosting: The compressor stops and the evaporation fan remains operational
- 5) Dripping time: After the defrosting is completed, in order to eliminate the accumulated water generated during defrosting and prevent icing again, the defrosting dripping time is set. During the defrosting and dripping time, the compressor, evaporator fan, and condenser fan all stop running. It can be set through the temperature controller (F5).

3.2. Defrosting mode

- 1) Forced defrosting: Press and hold the "Forced defrosting" button on the temperature controller, and if the defrosting conditions are met, the refrigerator will be forced to enter the defrosting state
 - 2) Timing defrosting: When the temperature of the refrigeration cabinet pipeline is lower than the defrosting stop temperature, and the compressor is turned on and running for the set time (set by the temperature controller), it automatically enters defrosting mode.
 - 3) Defrosting stop conditions
 - 4) Defrosting stop conditions:
 - 5) Active stop: After the refrigerator enters defrosting mode, if the temperature of the pipeline inside the refrigerator is detected to be higher than the defrosting stop temperature(F6), the refrigerator actively exits defrosting mode.
- ① Active stop: After the refrigerator enters defrosting mode, if the temperature of the pipeline inside the refrigerator is detected to be higher than the defrosting stop temperature(F6), the refrigerator actively exits defrosting mode.
- ② Automatic stop: After the refrigerator enters defrosting mode, if the temperature of the refrigerator pipeline is lower than the defrosting stop temperature(F6), it will automatically exit defrosting mode after defrosting time (F3).
- ③ Forced exit from defrosting: You can forcibly exit the current defrosting by long pressing the forced defrosting button on the temperature controller; No dripping time during forced exit;

4. Overtemperature alarm function

After detecting that the compressor has been running for 2 hours with electric refrigeration, the buzzer will output if the temperature inside the cabinet is greater than the starting temperature+5 or the temperature inside the cabinet is less than the stopping temperature -5 for more than 10 minutes. (The relevant control parameters can be adjusted through temperature controllers F7, F8, and F9, and the actual settings of the current unit shall prevail when leaving the factory)

5. Electromagnetic valve control

- 1) Opening conditions of spray solenoid valve/electronic spray expansion valve:
During the operation of the compressor, when the exhaust temperature is detected to be ≥ 90 (parameter P16 60-120 can be set), the solenoid valve is powered on/the electronic spray expansion valve opens. When the exhaust temperature is ≤ 75 (parameter P17 50-110 can be set), the solenoid valve is powered off/the electronic spray expansion valve closes.
- 2) Main refrigeration solenoid valve: the compressor is opened in advance, and when the compression is closed, the solenoid valve is closed;

6. Controller protection function

- 1) ON/OFF Control
If this port on the main control board is closed, the entire machine will operate normally according to the target temperature; If this port is disconnected, the entire machine will stop standby and the digital tube will display OFF
- 2) High and low pressure protection.
If the pressure protection port is disconnected, the controller displays the corresponding high and low voltage protection fault code, and the unit shuts down.
The low-pressure port is not detected within 1 minute of starting the compressor.

7. Main control board debugging/operation

7.1. Key operation

The controller status can be queried and set through the main control
Key definition: **Down key (-)**; **Confirm key (OK)**; **Up key (+)** (from left to right); Refer to the 'Schematic Diagram of the functional connection of the main control board' for detailed information.
The main control board defaults to displaying the operating frequency;
Flashes to display the type of fault and displays Exx when there is a fault;
By pressing the up and down keys, you can enter the status query information and display C00;
By long pressing the confirm button (3s), you can exit the parameter query interface;
Under the default interface, long press the confirm button (3s) to enter the parameter setting interface, displaying P00; Select the parameters that need to be changed or queried through+/-, and then click OK to change and set the current parameters;
Under the parameter setting interface, parameters can be set by pressing the+/- keys; By pressing the confirm button, you can save the set parameters and return to the query status;

7.2. Status Query Table

Code	Meaning	Description
C00	operating frequency	
C01	AC current (effective value)	
C02	Operating phase current (peak)	
C03	AC voltage	
C04	Bus voltage	
C05	Driver board fault codes	EXX corresponds to the drive board FXX and E00, indicating no faults
EXX corresponds to the drive board FXX and E00, indicating no faults		
C06	Frequency limiting code	
C07	Radiator temperature	
C08	Main control fault code	
C09	Condensing temperature	
C10	Return air temperature	
C11	Ambient temperature	
C12	Discharge temperature	
C13	Cabinet temperature	
C14	Evaporator temperature	
C15	Low pressure sensor value	100=1Mpa=10bar
C16	0/1/2 Defrosting type	Thermostat F14
C17	^^EEV1^S Current EEV1 opening	
C18	Current EEV2 opening	
C19	Current fan 1 speed	Only use DC FAN
C20	Current fan 1 speed	Only use DC FAN
C21	Current overheating	Cyclic Refresh
C23	Recent fault records	

7.3. Controller setting parameters

1) Electronic expansion valve related settings

Code	Meaning	min	Max	Default	Unit
P00	EEV1 Minimum opening	50	100	50	Step
P01	EEV1 Maximum opening	450	500	500	Step
P02	EEV1 Default initial opening	100	450	180	Step
P03	Initial opening duration	50	500	150	second
P04	EEV1 adjusts Kp value	1	200	18	
P05	EEV1 regulates Ki value	1	200	4	
P06	EEV1 regulates Kd value	1	200	8	
P07	EEV1 adjustment cycle	20	1000	60	second
P08	EEV2 Minimum opening	50	100	50	Step
P09	EEV2 Maximum opening	450	500	500	Step
P10	EEV2 Default initial opening	100	450	200	Step
P11	EEV2 Initial opening duration	30	500	30	second
P12	EEV2 adjusts Kp value	1	200	18	
P13	EEV2 regulates Ki value	1	200	4	
P14	EEV2 regulates Kd value	1	200	8	
P15	EEV2 adjustment period	50	500	60	second
P32	The EEV1 opening does not decrease when the exhaust temperature is high	60	120	70	°C
EEV1 opening does not decrease when discharge temperature is high					
P33	The EEV1 opening does not decrease when the exhaust temperature is high	10	80	30	°C
EEV1 opening does not increase when discharge temperature is low					
P34	Type of refrigerant	0	2	0	
0: R404 1:R448 2:R290					
P35	Overheating degree	0	50	4	
P36	opening during defrosting	50	500	100	Step

Note: EEV1 slot defaults to controlling the main electronic expansion valve, and EEV2 defaults to controlling the spray cooling electronic expansion valve

2) Compression related parameter settings

Code	Meaning	min	Max	Default	Unit
P16	Minimum frequency	10	50	30	Hz
P17	Maximum frequency	30	120	70	Hz
The P17 value cannot be set to be less than P16 setting value (Compressor operating frequency)					
P18	Compressor PID cycle	5	500	60	second
P19	Compressor Kp value	1	200	35	
P20	Compressor Ki value	1	200	10	
P21	Oil return frequency	10	70	35	Hz
Entering return oil logic during continuous low-frequency operation					
P22		10	80	50	Hz
P22 Operating frequency during oil return					
P23	Oil return interval time	5	600	225	min
P24	Return oil running time	5	1000	300	second
P40	Minimum press downtime	60	1000	180	second
P40 Minimum downtime of the compressor					
P31	Target temperature compensation	0	5	1	°C
P31 Target temperature compensation					

3) Fan and spray control

Code	Meaning	min	Max	Default	Unit
P26	Spray cooling opening Temp	60	120	90	°C
P27	Spray cooling off Temp	50	120	75	°C
P41	AC Fan on Temp	15	105	35	°C
P42	AC Fan off Temp	10	100	30	°C
P51	AC fan ambient start and stop temperature	10	100	32	°C
P51 The temperature at which the AC fan is forced to start when the ambient temperature is high					
P43	Low wind speed of DC fan	50	500	100	RPM
P44	High wind speed of DC fan	500	1200	900	RPM
P45	DC fan control Temp	10	20	10	°C
P46	Fan delay shutdown time	0	240	10	second
P46 Delayed shutdown time of fan					
P47	Low voltage switch delay judgment time	0	240	0	second
P47 Low pressure switch delay judgment time					

4) Operation protection related settings

Code	Meaning	min	Max	Default	Unit
P28	Low voltage switch delay judgment time	50	50	35	0.5A
P28 Compressor phase current too high shutdown point					
P29	Exhaust temperature is too high shutdown temperature	120	120	110	°C
P29 High discharge temperature shutdown temperature					
P30	Condenser high temperature overload shutdown	80	80	55	°C
P30 High condensation temperature shutdown temperature					

5) Defrost settings

Code	Meaning	min	Max	Default	Unit
P37	Compressor defrosting timing method	0: Control board power-on timing		0	
		1: Compressor start timing			
0:Start timing when the control board is powered on ;1 Start timing when the compressor is turned on					

8. Fault Code Table

1) Main control board fault code

Code	Fault Type	Cause/Solution
E00	Communication Failure	Check the communication line connection of the temperature controller
E01	Return air Temp sensor malfunction	Check if the corresponding sensor on the main control board has poor contact or is damaged
E02	Environmental Temp sensor failure	
E03	Condensation Temp sensor malfunction	
E04	Discharge Temp sensor malfunction	
E05	Cabinet Temp sensor failure	Check if the corresponding sensor of the Temp controller
E06	Evaporator Temp sensor malfunction	
E07	Low pressure protection	Low pressure protection/sensor damage
E08	High pressure protection	High pressure protection
E09	Drive communication failure	Check the connection between the driver board and the motherboard
E10	DC fan failure	Check the connection of the DC fan
E11	Drive failure	Current driver board faults can be viewed through C05
E13	Condensation overload fault	Excessive condensation Temp
E14	discharge Temp protection fault	discharge Temp too high
E15	AC current overcurrent fault	Controller current too high

2) Driver board fault codes

Note: When the main control board generates an E11 drive fault, the current drive fault code can be queried through the main control board C05;

Used for C05 query comparison

Code	Fault Type	Reason/Solution
F01	DC input overvoltage	Check input power
F02	DC input low voltage	Check input power
F03	Phase current output overcurrent	Abnormal motor
F04	Out of step fault	Abnormal drive board or motor
F05	Missing phase error O (speed judgment)	
F06	Phase loss error (current judgment)	
F07	Inverter IPM fault (edge)	The driver board is abnormal and needs to be updated or replaced
F08	Inverter IPM fault (level)	
F09	PFC_ IPM fault (edge)	
F10	PFC_ IPM fault (level)	
F11	AC power supply phase loss	Check input power
F12	AC overcurrent fault	
F13	Total power overload fault	Check compressor operation
F14	Abnormal AC voltage detection	Check input power
F15	Abnormal bias voltage detection	Check input power
F22	Communication failure	Check the communication line
F23	Motor parameter setting fault	The driver board is abnormal and needs to be updated or replaced
F24	DC motor fault	Check compressor operation
F28	Control board temperature abnormality	Drive board Temp too high
F29	Thermal protection fault	Drive board thermal protection

9. Annex

1. Controller reference circuit Diagram

The actual controller used may use different drive boards due to the current power of the unit, so the wiring method may vary. Please refer to the configuration of the actual unit.

